


Cartesian flat 3D printer safety guidelines

SAFETY GUIDELINES

- **Warning:** There is a risk of shock. Do not attempt to service this product.
- **Warning:** Do not leave the printer unattended during operation.
- **Warning:** Disconnect the 3D printer from the wall socket after use.
- **Caution:** In case of emergency, disconnect the printer from the wall socket.

With the support of HITSA IT Academy programme.



Licensed under a Creative Commons
Attribution-Noncommercial-Share Alike 4.0 License
<http://creativecommons.org/licenses/by-nc-sa/4.0/>



Compiled by **Madis Kaasik and Lauri Kilusk, Estonian Academy of Arts**, January 2021