

EKA

Delta 700 3D-printeri seaded Repetier-Hosti jaoks

Teave

Mitteäriiliseks kasutuseks saab tarkvara tasuta alla laadida ja kasutada (<http://www.repetier.com>). Soovitatav on vanem 1.0.6-versioon.


Repetier-Hosti tarkvara häälestamiseks on olemas seadete fail. Repetier-Hosti paigaldamise järel tuleb seadete fail programmi importida. Seadete rakendumiseks tuleb Repetier-Host pärast faili importimist taaskäivitada. Mõned seaded tuleb määrata käsitsi (toodud allpool).

Konfigureerimise sammud

(Need seaded on vaja konfigureerida vaid ühel korral peale tarkvara installatsiooni)

- 1.** Ava tarkvara
- 2.** Navigeeris seadete paneeli (Settings)
- 3.** Konfigureeri seaded vastavalt kuvatõmmistele

Printer Settings

Printer: 

Connection **Printer** Extruder Printer Shape Advanced

Connector:

Port:

Baud Rate:

Transfer Protocol:

Reset on Connect:


Reset on Emergency:

Receive Cache Size:

Use Ping-Pong Communication (Send only after ok)

The printer settings always correspond to the selected printer at the top. They are stored with every OK or apply. To create a new printer, just enter a new printer name and press apply. The new printer starts with the last settings selected.

Printer Settings

Printer: 

Travel Feed Rate: [mm/min]

Z-Axis Feed Rate: [mm/min]

Manual Extrusion Speed: [mm/s]


Manual Retraction Speed: [mm/s]

Default Extruder Temperature: °C

Default Heated Bed Temperature: °C

Check Extruder & Bed Temperature

Remove temperature requests from Log

Check every 3 seconds. 

Park Position: X: Y: Z min: [mm]

Send ETA to printer display Go to Park Position after Job/Kill

Disable Extruder after Job/Kill Disable Heated Bed after Job/Kill

Disable Motors after Job/Kill Printer has SD card

Add to comp. Printing Time [%]

Invert Direction in Controls for X-Axis Y-Axis Z-Axis

Printer Settings

Printer: default



Connection Printer **Extruder** Printer Shape Advanced

Number of Extruder: 1

Max. Extruder Temperature: 50

Max. Bed Temperature: 120

Max. Volume per second 12 [mm³/s]

Printer has a Mixing Extruder (one nozzle for all colors)

Extruder 1

Name:

Diameter: 2 [mm] Temperature Offset: 0 [°C]

Color:


Offset X: 0 Offset Y: 0 [mm]

OK

Apply

Cancel

Printer Settings

Printer: 

Connection Printer Extruder Printer Shape Advanced


Printer Type:

Home X: Home Y: Home Z:

Printable Radius: mm

Printable Height: mm

Printer Settings

Printer: 

Connection Printer Extruder Printer Shape **Advanced**

Post Slice Filter

Filter Path and Parameter:

Run Filter after every Slice

You can run a filter program after each slicing action. The filter will be run on the G-Code produced by the slicer. Use #in and #out to insert the input and output filenames as parameter.

OK

Apply

Cancel

Valminud Hariduse Infotehnoloogia Sihtasutuse IT Akadeemia programmi toel.



Õppematerjalile kohaldatakse järgmist Creative Commonsi Eesti litsentsi (versioon 4.0):
autorile viitamine, mitteäriline eesmärk, jagamine samadel tingimustel
<http://creativecommons.org/licenses/by-nc-sa/4.0/>



Koostanud **Madis Kaasik ja Lauri Kilusk, Eesti Kunstiakadeemia**, jaanuar 2021