


**Moineau smart pump
safety guidelines**

SAFETY GUIDELINES

- **Warning:** Don't leave the pump unattended during operation
- **Warning:** Disconnect the pump from the wall socket after use
- **Warning:** Disconnect the pump from the wall socket for filling and cleaning
- **Warning:** Don't put your hand into the container if the pump is connected to the wall socket
- **Warning:** There is a risk of shock. Do not try to service the product.
- **Warning:** Don't use a hose longer than 5 meters
- **Warning:** Never allow the pressure in the hose to reach 16 bar or above
- **Caution:** In case of emergency, press one of the emergency stop buttons
- **Caution:** Use the black safety canvas to rap the pump/hose connection
- **Caution:** Use the safety pins for hose quick-connectors
- **Caution:** Don't start the pump with pump speeds turned up high

With the support of HITSA IT Academy programme.



Licensed under a Creative Commons
Attribution-Noncommercial-Share Alike 4.0 License
<http://creativecommons.org/licenses/by-nc-sa/4.0/>



Compiled by **Madis Kaasik and Lauri Kilusk, Estonian Academy of Arts**, January 2021